

**HIGH PERFORMANCE** 

Brazilian Rotisserie with Fire Box



EXAMPLE OF THE PHOTO: BARBECUE 620 ROTARY WITH 11 SKEWERS + FIRE BOX

Wildwood Ovens & BBQ's 5020 Eagle Rock Blvd Los Angeles, CA 90041

#### ef 🖸 🗖 🖻

# **Equipment Feature**

### **Available Sizes**


• Equipment available in 07 sizes for rotary system: from 19 -" for 5 skewers up to 42" for 17 skewers.

### **BENIFITS**

• Roast meat on rotating skewers and spread the embers of the brazier; • Configuration of the size of the brazier and the skewers according to the needs of each client; • On/off button attached to the equipmaneto; • Support angle for parade grid; • the unit has two speeds in the rotating system: one to sear another for roasting.


## INSTALLATION OF THE EQUIPMENT

 Easy installation, just place the equipment inside the masonry and plug into the outlet; • Do not install the product exposed to weather and sea.









## NET WEIGHT OF THE PRODUCT / MEASUREMENTS AND WEIGHTS OF THE PRODUCT PACKED IN INCHES

ROTISSERI	Weight	Fire Box	Weight	PACKAGING	WEIGHT	CARATE DIMENSIONS
485 - 06 Skewer	44 lb	Fire Box 12"	37 lb	30	56 lb	44 X 32 X 2 7
585 - 07 Skewer	50 lb	Fire Box 15"	41 lb	39	60 lb	49X 32 X 27
685 - 09 Skewer	59 lb	Fire Box 20"	48 lb	42	62 lb	52 X 32X 27
785 - 11 Skewer	66 lb			46	68 lb	56X32X 27
885 - 13 Skewer	72 lb			50	70 lb	60X 32 X 27
985 - 15 Skewer	79 lb			54	72 lb	64X32X 27
1.085 - 17 Skewer	85 lb			58	76 lb	68 X 32 X 27

## **ADITIONAL INFORMATION**

Electrical: 120 / 220 Volt Frequency " 50/60Hz

## **IMPORTANT**

Use only charcoal inside the fire box, any other combustible material will damage your rotating system; • Use firewood, wood or slings to make fire ONLY inside the FIRE BOX; • The barbecue cabinet can never stay inside the fire casket, i.e. in the fire.

